SAMSUNG

UterineContour™

V Series Quick Guide




Produced by Clinical Training Center / SAMSUNG MEDISON CO.,LTD

UterineContour™


1. Start UterineContour™ (1)






1 Image Acquisition	Acquire the sagittal uterine view with 3D endovaginal probe.
2 Start Uterine Contour	Tap [Uterine Contour] button on the touch screen to start.
3 Contour ROI	Contour ROI is automatically drawn and 3D coronal view is displayed.

2. Start UterineContour™ (2)




1 Image Acquisition	Acquire the sagittal uterine view with 3D endovaginal probe and volume data.
2 Start Uterine Contour	Touch the [Oblique] tab.
3 Touch [Auto Contour] button.	Contour ROI is automatically drawn and 3D coronal view is displayed.


3. Further manipulation







4. Set up



Set up user's standard value

- 1. Classification guideline can be set in Measure Setup > Measure > Gynecology
- 2. There are two types of Uterine Classification
- ESHRE/ESGE
- ASRM

- The features, options may not be commercially available in some countries.
- Sales and shipments are effective only after the approval by the regulatory affairs. Please contact your local sales representative for further details.
- This Quick guide does not include all of the details of instruction, fore more detail, please refer to V series User Manual.
- Do not distribute this document to customers unless relevant regulatory and legal affairs officers approve such distribution.
- This User Quick Guide is based on V series V1.05.
- Disclaimer: Some Images in this content were obtained from other system.

SAMSUNG MEDISON CO., LTD.

© 2024 Samsung Medison All Rights Reserved.
Samsung Medison reserves the right to modify the design, packaging, specifications, and features shown herein, without prior notice or obligation.